

# HindPhotostat



## Hind Photostat & Book Store

Best Quality Classroom Topper Hand Written Notes to Crack GATE, IES, PSU's & Other Government Competitive/ Entrance Exams

**MADE EASY  
ELECTRONICS ENGINEERING  
CO -FOR GATE  
BY-SAGAR**

- Theory
- Explanation
- Derivation
- Example
- Shortcuts
- Previous Years Question With Solution

Visit us:-[www.hindphotostat.com](http://www.hindphotostat.com)

Courier Facility All Over India  
(DTDC & INDIA POST)  
Mob-9311989030



# HindPhotostat



**MADE EASY , IES MASTER , ACE ACADEMY , KREATRYX**

**ESE , GATE, PSU BEST QUALITY TOPPER HAND WRITTEN NOTES  
MINIMUM PRICE AVAILABLE @ OUR WEBSITE**

- |                                |                           |
|--------------------------------|---------------------------|
| 1. ELECTRONICS ENGINEERING     | 2. ELECTRICAL ENGINEERING |
| 3. MECHANICAL ENGINEERING      | 4. CIVIL ENGINEERING      |
| 5. INSTRUMENTATION ENGINEERING | 6. COMPUTER SCIENCE       |

**IES , GATE , PSU TEST SERIES AVAILABLE @ OUR WEBSITE**

- ❖ IES –PRELIMS & MAINS
- ❖ GATE

➤ **NOTE;- ALL ENGINEERING BRANCHS**

➤ **ALL PSUs PREVIOUS YEAR QUESTION PAPER @ OUR WEBSITE**

## **PUBLICATIONS BOOKS -**

**MADE EASY , IES MASTER , ACE ACADEMY , KREATRYX , GATE ACADEMY , ARIHANT , GK  
RAKESH YADAV , KD CAMPUS , FOUNDATION , MC –GRAW HILL (TMH) , PEARSON...OTHERS**

**HEAVY DISCOUNTS BOOKS AVAILABLE @ OUR WEBSITE**

<b>F230, Lado Sarai New Delhi-110030 Phone: 9311 989 030</b>	<b>Shop No: 46 100 Futa M.G. Rd Near Made Easy Ghitorni, New Delhi-30 Phone:9711475393</b>	<b>F518 Near Kali Maa Mandir Lado Sarai New Delhi-110030 Phone: 9560 163 471</b>	<b>Shop No.7/8 Saidulajab Market Neb Sarai More, Saket, New Delhi-30</b>
--	--	--	--

**Website: [www.hindPhotostat.com](http://www.hindPhotostat.com)**

**Contact Us: 9311 989 030**

**Courier Facility All Over India**



**(DTDC & INDIA POST)**

# Computer Organization

- father of computer → Charles Babbage
- 1<sup>st</sup> electronic computer ⇒ ENIAC  
(Electronic Numerical Integrator and Calculator)

Computer ⇒ It is a fast electronic calculating machine which accepts digitized i/p information and processes it with the help of internally stored instructions known as program and produces the resultant o/p information.


Block dig diagram of computer ⇒



- ① first computer has issues in →
- 1) Vacuum tube
  - 2) Electrical issue
  - 3) mechanical issue
  - 4) large weight
- } this issue resolved by using transistor (smaller, faster, less power)

• transistor invented by John Bardeen, William Shockley, Walter Brattain.

- ②
- 1<sup>st</sup> gen. computer made of vacuum tube,
  - 2<sup>nd</sup> gen. computer made of by using transistor.
  - 3<sup>rd</sup> gen. computer → IC.




SI (small scale Integration) < 10 transistor

MSI = 10 - 100

LSI = 100 - 1k transistor

VLSI = > 1k / 10k transistor

- Microprocessor ( $\mu p$ ) ⇒ it is a semiconductor component design by using VLSI technologies. and it contain ALU, CU and registers of a CPU. in a single package



Note for a basic  $\mu p$  (microprocessor), memory is connected externally. the registers inside the processor can't not be

considered as memory as their used to store or hold the data temporarily.


• In latest processor some memory present inside to store frequently used data and instruction, known as cache memory.

• Functions of computer  $\Rightarrow$

- (1) Data storage
- (2) Data processing
- (3) Data movement
- (4) Data Control

• functionality of computer  $\Rightarrow$

stored program concept  $\Rightarrow$  invented by John <sup>Von</sup> Neumann.



Computer uses binary language: 1 and 0

Bit  $\Rightarrow$  Binary digit  $\Rightarrow$  0, 1, bits denotes by b

nibble  $\Rightarrow$  4 bits

Byte  $\Rightarrow$  8 bits

word length  $\Rightarrow$  depends on type of up  
 $\Rightarrow$  no. of bits that can be processed by up a processor parallelly at a time in the ALU.

$\Rightarrow$  no. of bits that can be accessed from memory at a time (either for read or write operation)

⇒ the processor are generally identified by number of data bits that can be handle at a time that is word length.

① 1<sup>st</sup> up manufactured (1971) → Intel 4004 → 4 bit up <sup>word length</sup>  
1972 → Intel 8008 → 8 bit up / 1 byte  
1974 → Intel 8080 → 8 bit up  
1976 → Intel 8085 → 8 bit up

↑  
1<sup>st</sup> up used for commercial application


→ Intel 8086 → 16 bits / 2 bytes

→ Intel 80186 → 32 bit up

Intel 80386

Pentium ... Dual core - i<sub>3</sub>

Dual core → having 2 CPU <sup>IC</sup>




Computer works in binary language, but in real work all are in analog form. also need a interface circuit physical parameters

to convert analog signal to binary and binary to analog signal.

Ex → ADC, DAC,

physical parameter → light  
→ temperature  
→ Pressure  
→ humidity

# microcontroller



difference b/w  $\mu p$  and  $\mu c$ .

$\mu p$

$\mu c$

- |   |   |
|---|---|
| 1) it has ALU, CU and registers                                 | 1) has ALU, CU and Registers.   |
| 2) <u>No internal memory</u>                                    | 2) has internal / on-board memory   |
| 3) <u>No interfacing circuits</u> ,<br>Timers / counters        | 3) has interfacing circuits, timer / counter.   |
| 4) used for <u>general purpose application</u> .                | 4) Used for <u>specific purpose application</u> .   |
| Example :- Computer, mobile,                                    | Example $\Rightarrow$ home applications like AC, washing mach, microwave oven, Refrigerator, mouse, defence, medical equipment, lab, Commun |
| 5) Requires more memory   | 5) Require less memory because specific purpose   |
| 6) More hardware  | 6) less hardware  |
| 7) Costly   | 7) Cheap  |
| 8) Example of $\mu p \Rightarrow$ intel 8085, i3, i4, motorola, | 8) $\mu c \rightarrow$ 1st $\mu c \rightarrow$ TMS1000 (4 bit intel 8051 (8 bit)  |

• Depending on how programs and data are stored in the memory there are two type of architecture.



Von-Neumann  
(or)

Princeton  
Architector


Harvard  
Architector

Example - Intel 8085,  
intel 8086

Example → intel 8051  
↑  
MC



Basic operations of  $\mu P \Rightarrow$



- 1) opcode fetch
- 2) memory Read (M/M read)
- 3) memory write (M/M write)
- 4) I/O read
- 5) I/O write

machine language  
 (0100 0001)  
41H



1) opcode fetch  $\Rightarrow$  Reading or accessing the instruction i.e. opcode or operational code from memory into processor. (in some instructions executions may also be completed in fetch operation with respect to certain process like 8085)

2) M/M read  $\Rightarrow$  reading or accessing data from memory into Processor.

3) M/M write  $\Rightarrow$  sending or transferring data to memory from the ~~profes~~ processor.

4) I/O read  $\Rightarrow$  Reading or accessing data from i/p port or device into processor.  
Port indicates connection of an I/O device.

5) I/O write  $\Rightarrow$  sending or transferring data to the o/p port or device.

Note with respect to memory, there is no difference b/w instruction and data both are present in binary form.

• generally the processor can perform two <sup>basic</sup> operation read and write w.r.t. memory and I/O device.

Computer Architecture  $\Rightarrow$

1) attributes of a S/S visible to a programmer (or) that have direct impact on logical execution of a program  
Example  $\Rightarrow$  Instruction set design,

Addressing modes

(or)  
2) study of functional operation of individual hardware units w.r.t. Computer S/S along with flow of information b/w them through proper controlled among them.

## Computer organization ⇒

- it refers to the operational units and their interconnection that realize the architectural specification.
- Computer organization involves
  - (1) memory s/s
  - (2) M/M interconnection
  - (3) Design of CPU
- When a new computer has to be design, performance, efficiency at the same time, cost, power consumption, availability should also be taken into care.

## Basic classes of computer ⇒

- (1) PMD → (Personal mobile Device)
- (2) Desktop computer
- (3) Servers
- because of software as a service many applications are possible like search, gaming, web application etc.
- few servers are connected <sup>to</sup> the lane.
- if thousand of such servers are required for a certain applications it is known as warehouse scale
- In other complex applications at high end like weather forecasting, scientific research, space technology ~~say~~ super computer used,

## Top level structure of computer ⇒

