

HindPhotostat



Hind Photostat & Book Store

Best Quality Classroom Topper Hand Written Notes to Crack GATE, IES, PSU's & Other Government Competitive/ Entrance Exams

MADE EASY
ELECTRONICS ENGINEERING
Microwave
By- Rathi Sir

- Theory
- Explanation
- Derivation
- Example
- Shortcuts
- Previous Years Question With Solution

Visit us:-www.hindphotostat.com

Courier Facility All Over India
(DTDC & INDIA POST)
Mob-9311989030

2 Microwave 2

① Introduction

② MW components

↳ E-plane Tee

↳ H-plane Tee

↳ Magic Tee [E-H plane Tee] [3 Marks]
↳ S-Matrix [Hybrid Tee]

↳ Rat race Junction

↳ Directional coupler [15 Marks]

↳ Ferrite device

⇒ Isolator

⇒ Gyralin

⇒ circulator [6 Marks]

③ MW signal generation & application

↳ MW Tubes

↳ Limitation of conventional tubes [8 Marks]

↳ Two cavity klystron

↳ Multi cavity klystron

↳ Reflex klystron → oscillator

[15 Marks] → Amplifier

↳ TWT [15 Marks] → Amplifier

↳ BWO → oscillator

↳ Magnetron [15 Marks] → oscillator

④ Solid state device.

↳ Gun Diode [15 Marks]

↳ Tunnel diode [10 Marks]

↳ Avalanche transit time device

⇒ IMPATT [Read Diode] [20 Marks]

⇒ TRAPATT

⇒ BARITT

INDIAN INSTITUTE OF TECHNOLOGY
F-21-A, LAJOSARAI, NEW DELHI-30
8130782342

↳ Parametric Amplifier [15 Marks]

↳ MASER & LASER

↳ Cavity Resonator

⑤ MW measurement [10 Marks]

⑥ MW communication

↳ Terrestrial comm.

↳ Satellite comm. [15 Marks]

⑦ Microwave Antenna

⑧ microstrip [8 Marks]

↳ Introduction

→ MW Frequency range

300 MHz to 300 GHz

MW devices can be used upto 10^6 GHz. i.e. 10^{15} Hz

$$c = \lambda f$$

$$\lambda = \frac{c}{f}$$

$$c = 3 \times 10^8 \text{ m/sec}$$

↳ case-1

$$f = 300 \text{ MHz}$$

$$\lambda_1 = \frac{3 \times 10^8}{300 \times 10^6} = 1 \text{ m}$$

↳ case-2

$$f = 300 \text{ GHz}$$

$$\lambda_2 = \frac{3 \times 10^8}{300 \times 10^9} = 1 \text{ mm}$$

↳ case-3

$$f = 10^6 \text{ GHz}$$

$$\lambda_3 = \frac{3 \times 10^8}{10^6 \times 10^9} = 0.3 \text{ m}$$

In case-3 $\lambda_3 = 0.3 \text{ m}$ (in the range of cm)
hence the name microwave.

⇒ MW are so called because they are defined in terms of their wavelength.

⇒ Advantage of MW

gt Res. B.W. availability.

B.W. is some % of center frequency

Let B.W. is 1% of center frequency


B.W. of T.V. channel in India = 7 MHz.

Audio signal - FM

Video signal - VSB (AM)

carrier freq.	BW	No. of TV channel
70 MHz	0.7 MHz	0
700 MHz	7 MHz	1
7 GHz	70 MHz	10
70 GHz	700 MHz	100


↳ Improved directive property



$\theta \rightarrow$ Beam width

$$\text{Directivity} \propto \frac{1}{\theta}$$

$$\theta \propto \lambda$$




$$\theta' < \theta$$

$$f \uparrow \quad \lambda \downarrow \quad \theta \downarrow \quad D \uparrow$$

so, high gain & directive antenna can be designed & fabricated more easily at MW frequency.

→ Fading effect and Reliability



Due to line of sight propagation & high freq. there is less fading effect & MW comm. is more reliable.

→ Power requirements


Tx & Rx power requirements is very low at MW frequency.

$$P_0 \propto \frac{1}{f}$$

↳ Receiving power requirements

→ Transparency property of MW

MW frequency bands are capable of free propagation through ionised layer (ionosphere) surrounding the earth.



Q-wave can penetrate ionospheric layer.

Ionospheric comm. (sky wave propagation).

→ Size of component is directly proportional to wavelength, therefore smaller system is possible.

⇒ Application

↳ Telecommunication

↳ Intercontinental Telephone & TV, space comm., telemetry comm. link for railways.

↳ Radar

↳ Commercial & Industrial application uses heating property of Q-wave

eg. - Q-wave oven

- Drying machine


- Machine / Public works

- Food processing industry

↳ Biomedical application

↳ Electronic warfare

⇒ Relation between path travelled and phase change



Path travelled	Phase change
λ	2π
$\lambda/2$	π
$\lambda/4$	$\pi/2$
l	$\frac{2\pi}{\lambda} \cdot l$

Rate of change of phase $\rightarrow \omega = \frac{d\theta}{dt} = 2\pi f = \frac{2\pi}{T}$


$$f = \frac{1}{T}$$

eg $f = 50 \text{ Hz}$; $T = \frac{1}{f} = 20 \text{ msec}$

$$\lambda = \frac{c}{f} = \frac{3 \times 10^8}{50} = 6 \times 10^6 \text{ m} = 6000 \text{ km}$$

& if $f = 10^6 \text{ GHz}$; $\lambda = 0.3 \text{ m}$

$$\phi = \frac{2\pi}{\lambda} \cdot l = \frac{2\pi}{6 \times 10^6} \times 1 \approx 0$$




$$\phi = \frac{2\pi}{6 \times 10^6} \times 1 \approx 0$$

[lumped parameter]

R, L, C

because rate of change of phase is very low



$$\phi = \frac{2\pi}{0.3 \times 10^{-6}} \times 1$$

[distributed parameter]

1 m , farad/m ; H/m

when λ is large there is negligible phase variation across the components so lumped parameter or simple ckt. theory is applicable for small λ there is high phase variation across the components therefore λ -wave components are represented as distributed parameter.


↳ Band designation

IEEE : Institute of electrical & electronics eng.

Band	Freq. range
L	1-2 GHz
S	2-4 GHz
e	4-8 GHz
X	8-12 GHz
KU	12-18 GHz
K	18-27 GHz
Ka	27-40 GHz

HIND PHOTOSTAT
F-21-A, LADOSARAI, NEW DELHI-30
8130782342

⇒ q-wave components




$$\begin{bmatrix} V_1 \\ V_2 \end{bmatrix} = \begin{bmatrix} Z_{11} & Z_{12} \\ Z_{21} & Z_{22} \end{bmatrix} \begin{bmatrix} I_1 \\ I_2 \end{bmatrix}$$

If the frequencies are in q-wave range then h, Y, Z -parameters can't be used for following reasons:-

- ↳ Equipment is not readily ^{available} to measure total voltage & total current at the port of network.
- ↳ SC & OC are difficult to achieve over broad band of frequency.
- ↳ Active device such as power transistors, tunnel diode etc frequently will not have stability for SC or OC.

⇒ S-parameter [Scattering]



$$\begin{bmatrix} b_1 \\ b_2 \end{bmatrix} = \begin{bmatrix} S_{11} & S_{12} \\ S_{21} & S_{22} \end{bmatrix} \begin{bmatrix} a_1 \\ a_2 \end{bmatrix}$$